
## O

## **Textile exhibition wall**







Unfold the worm fence system by pulling apart the upper corners on the outside. Hold the system in place while you set it up.



Insert the plastic connectors between the feet of the system to increase stability.



Set the feet into the desired position using the adjusting screws.



Attach the print to the Velcro tape. Start with one of the corners on the front of the system, pull the print tight and stretch it across to the adjacent corner. Continue in this way to fix the entire print to the front of the system.



Pull the side parts of the print around the sides of the system until the outer edges of the print are on the back of the system.



Fix the print to the Velcro tape.



Here is your textile exhibition wall in full size.