



X banners



Remove the print and the X-banner system from the transport bag.



Expand the braces of the system fully. The brace that projects backwards is only used to improve the stability of the system.



Fix the print in the system. Start with the top and push the eyelets at the corners through the hooks on the braces for the system.



Then fix the lower eyelets on the system. Now the print and the system will be stretched out.



Here is your X-banner in full size.